



DEPARTMENT OF THE NAVY
ATLANTIC DIVISION
NAVAL FACILITIES ENGINEERING COMMAND
NORFOLK, VIRGINIA 23511

7
TELEPHONE NO.

(804) 444-9561
IN REPLY REFER TO:
114:DPG:gmc
6280

2 6 JUL 1983

From: Commander, Atlantic Division, Naval Facilities Engineering Command
To: Commanding General, Marine Corps Base, Camp Lejeune

Subj: Hazardous Waste Testing

Encl: (1) Sample Sheet No. 99

1. For your information the enclosure (1) results and sample pickup totaled \$4,939.00, leaving \$61.00 of your funds on-hand.

J. R. Bailey
fa J. R. BAILEY
By direction

CLW

0000006039



CENTEC ANALYTICAL SERVICES, INC.
A SUBSIDIARY OF THE CENTEC CORPORATION

26/8/83

P. O. BOX 956
2160 INDUSTRIAL DRIVE
SALEM, VIRGINIA 24153
(703) 387-3995

— ANALYTICAL RESULTS REPORT —

Mr. David Goodwin
Atlantic Division Code 1143
Naval Facilities Engineering Command
Norfolk, VA 23511

Re: Water Analysis
CAS Commission No. 6094

REPORT DATE/NUMBER: 08 July 1983/99

SAMPLE COLLECTED: 19 April 1983: 1300

BY: Lachope/Hunekutt

SAMPLE RECEIVED AT LAB: 21 April 1983: 1500

ANALYSIS FOR: Mercury (Hg), Silver (Ag), Arsenic (As),
Beryllium (Be), Cadmium (Cd), Chromium (Cr),
Copper (Cu), Nickel (Ni), Lead (Pb), Selenium
(Se), Zinc (Zn), Antimony (Sb), and Thallium
(Tl)

METHOD OF ANALYSIS: Re: Federal Register, Vol. 41, No. 232,
1 December 1976

The results are shown on the following page.

If you have any questions or comments concerning this report,
please do not hesitate to contact us.

Prepared by:

CENTEC ANALYTICAL SERVICES


David F. Tompkins
Chemist

DFT/mls

CLW

0000006040

Marine Corps Base, Camp LeJeune, N.C.
Naval Facilities Engineering Command
08 July 1983
Page 2

CAS No.	Description	Ag (mg/l)	As (mg/l)	Be (mg/l)	Cd (mg/l)	Cr (mg/l)	Cu (mg/l)	Hg (mg/l)	Ni (mg/l)	Pb (mg/l)	Se (mg/l)	Zn (mg/l)	Sb (mg/l)	Tl (mg/l)
29372	Field # 15 Landfill L													
29373	Field # 16 Landfill													
29374	Field # 17 Landfill													
29375	RR-45													
29376	RR-47													
29377	RR-92													
29378	Rifle Range finished water	<0.01	<0.001	<0.01	<0.05	<0.02	0.0007	<0.05	<0.001	<0.005	0.08	<0.001	<0.001	<0.001

CLW
000006041

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29372
 COMPUTECH SAMPLE NUMBER: 3493

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1V. ACRYLONITRILE	BDL	100	
2V. BENZENE	BDL	100	
3V. BIS (CHLOROMETHYL) ETHER	BDL	10	
4V. BROMOFORM	BDL	10	
5V. CARBON TETRACHLORIDE	BDL	10	
6V. CHLOROBENZENE	BDL	10	
7V. CHLORODIBROMOMETHANE	BDL	10	
8V. CHLOROETHANE	BDL	10	
10V. 2-CHLOROETHYLVINYL ETHER	BDL	10	
11V. CHLOROFORM	BDL	10	
12V. DICHLOROBROMOMETHANE	BDL	10	
13V. DICHLORODIFLUOROMETHANE	BDL	10	
14V. 1,1-DICHLOROETHANE	BDL	10	
15V. 1,2-DICHLOROETHANE	BDL	10	
16V. 1,1-DICHLOROETHYLENE	BDL	10	
17V. 1,2-DICHLOROPROPANE	BDL	10	
18V. 1,3-DICHLOROPROPYLENE	BDL	10	
19V. ETHYLBENZENE	BDL	10	
20V. METHYL BROMIDE	BDL	10	
21V. METHYL CHLORIDE	BDL	10	
22V. METHYLENE CHLORIDE	BDL	10	
23V. 1,1,2,2-TETRACHLOROETHANE	BDL	10	
24V. TETRACHLOROETHYLENE	BDL	10	
25V. TOLUENE	BDL	10	
26V. 1,2-TRANS-DICHLOROETHYLENE	14	10	295
27V. 1,1,1-TRICHLOROETHANE	BDL	10	
28V. 1,1,2-TRICHLOROETHANE	BDL	10	
29V. TRICHLOROETHYLENE	BDL	10	
30V. TRICHLOROFLUOROMETHANE	BDL	10	
31V. VINYL CHLORIDE	BDL	10	

CLW

000006042

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29372
 COMPUCHEM SAMPLE NUMBER: 3493

<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1A. 2-CHLOROPHENOL	BDL	25	
2A. 2,4-DICHLOROPHENOL	BDL	25	
3A. 2,4-DIMETHYLPHENOL	BDL	25	
4A. 4,6-DINITRO-O-CRESOL	BDL	250	
5A. 2,4-DINITROPHENOL	BDL	250	
6A. 2-NITROPHENOL	BDL	25	
7A. 4-NITROPHENOL	BDL	25	
8A. P-CHLORO-M-CRESOL	BDL	25	
9A. PENTACHLOROPHENOL	BDL	25	
10A. PHENOL	BDL	25	
11A. 2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

000006043

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29372
 COMPUCHEM SAMPLE NUMBER: 3493

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006044

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29373
 COMPUCHEM SAMPLE NUMBER: 3494

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1V. ACRYLONITRILE	BDL	100	
2V. BENZENE	BDL	100	
3V. BIS (CHLOROMETHYL) ETHER	BDL	10	
5V. BROMOFORM	BDL	10	
6V. CARBON TETRACHLORIDE	BDL	10	
7V. CHLOROBENZENE	BDL	10	
8V. CHLORODIBROMOMETHANE	BDL	10	
9V. CHLOROETHANE	BDL	10	
10V. 2-CHLOROETHYLVINYL ETHER	BDL	10	
11V. CHLOROFORM	BDL	10	
12V. DICHLOROBROMOMETHANE	BDL	10	
13V. DICHLORODIFLUOROMETHANE	BDL	10	
14V. 1,1-DICHLOROETHANE	BDL	10	
15V. 1,2-DICHLOROETHANE	BDL	10	
16V. 1,1-DICHLOROETHYLENE	BDL	10	
17V. 1,2-DICLOROPROPANE	BDL	10	
18V. 1,3-DICLOROPROPYLENE	BDL	10	
19V. ETHYLBENZENE	BDL	10	
20V. METHYL BROMIDE	BDL	10	
21V. METHYL CHLORIDE	BDL	10	
22V. METHYLENE CHLORIDE	BDL	10	
23V. 1,1,2,2-TETRACHLOROETHANE	13	10	641
24V. TETRACHLOROETHYLENE	BDL	10	
25V. TOLUENE	43	10	677
26V. 1,2-TRANS-DICHLOROETHYLENE	450	10	301
27V. 1,1,1-TRICHLOROETHANE	BDL	10	
28V. 1,1,2-TRICHLOROETHANE	BDL	10	
29V. TRICHLOROETHYLENE	31	10	470
30V. TRICHLOROFUOROMETHANE	BDL	10	
31V. VINYL CHLORIDE	BDL	10	

CLW

000006045

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29373
 COMPUCHEM SAMPLE NUMBER: 3494

<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1A. 2-CHLOROPHENOL	BDL	25	
2A. 2,4-DICHLOROPHENOL	BDL	25	
3A. 2,4-DIMETHYLPHENOL	BDL	25	
4A. 4,6-DINITRO-O-CRESOL	BDL	250	
5A. 2,4-DINITROPHENOL	BDL	250	
6A. 2-NITROPHENOL	BDL	25	
7A. 4-NITROPHENOL	BDL	25	
8A. P-CHLORO-M-CRESOL	BDL	25	
9A. PENTACHLOROPHENOL	BDL	25	
10A. PHENOL	BDL	25	
11A. 2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

000006046

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29373
 COMPUCHEM SAMPLE NUMBER: 3494

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006047

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29374
 COMPUCHEM SAMPLE NUMBER: 3495

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
IV. ACRYLONITRILE	BDL	100
2V. BENZENE	BDL	100
3V. BROMOFORM	13	10
4V. CARBON TETRACHLORIDE	BDL	10
5V. CHLOROBENZENE	BDL	10
6V. CHLORODIBROMOMETHANE	BDL	10
7V. CHLOROETHANE	BDL	10
10V. 2-CHLOROETHYL VINYL ETHER	BDL	10
11V. CHLOROFORM	BDL	10
12V. DICHLOROBROMOMETHANE	BDL	10
13V. DICHLORODIFLUOROMETHANE	BDL	10
14V. 1,1-DICHLOROETHANE	BDL	10
15V. 1,2-DICHLOROETHANE	21	10
16V. 1,1-DICHLOROETHYLENE	BDL	10
17V. 1,2-DICHLOROPROPANE	BDL	10
18V. 1,3-DICHLOROPROPYLENE	BDL	10
19V. ETHYLBENZENE	BDL	10
20V. METHYL BROMIDE	BDL	10
21V. METHYL CHLORIDE	BDL	10
22V. METHYLENE CHLORIDE	BDL	10
23V. 1,1,2,2-TETRACHLOROETHANE	BDL	10
24V. TETRACHLOROETHYLENE	BDL	10
25V. TOLUENE	BDL	10
26V. 1,2-TRANS-DICHLOROETHYLENE	4,700	1
27V. 1,1,1-TRICHLOROETHANE	BDL	10
28V. 1,1,2-TRICHLOROETHANE	BDL	10
29V. TRICHLOROETHYLENE	BDL	10
30V. TRICHLOROFUOROMETHANE	BDL	10
31V. VINYL CHLORIDE	28	

CLW

¹ Compound calculated from a 1:10 dilution

0000006048

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29374
COMPUCHEM SAMPLE NUMBER: 3495

	<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> (UG/L)	<u>DETECTION</u> <u>LIMIT</u> (UG/L)
1A.	2-CHLOROPHENOL	BDL	25
2A.	2,4-DICHLOROPHENOL	BDL	25
3A.	2,4-DIMETHYLPHENOL	BDL	25
4A.	4,6-DINITRO-O-CRESOL	BDL	250
5A.	2,4-DINITROPHENOL	BDL	250
6A.	2-NITROPHENOL	BDL	250
7A.	4-NITROPHENOL	BDL	25
8A.	P-CHLORO-M-CRESOL	BDL	25
9A.	PENTACHLOROPHENOL	BDL	25
10A.	PHENOL	BDL	25
11A.	2,4,6-TRICHLOROPHENOL	BDL	25

CLW

0000006049

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29374
 COMPUCHEM SAMPLE NUMBER: 3495

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006050

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29375
 COMPUCHEM SAMPLE NUMBER: 3496

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1V. ACRYLONITRILE	BDL	100
2V. BENZENE	BDL	100
3V. BROMOFORM	BDL	10
4V. CARBON TETRACHLORIDE	BDL	10
5V. CHLOROBENZENE	BDL	10
6V. CHLORODIBROMOMETHANE	BDL	10
7V. CHLOROETHANE	BDL	10
10V. 2-CHLOROETHYL VINYL ETHER	BDL	10
11V. CHLOROFORM	BDL	10
12V. DICHLOROBROMOMETHANE	BDL	10
13V. DICHLORODIFLUOROMETHANE	BDL	10
14V. 1,1-DICHLOROETHANE	BDL	10
15V. 1,2-DICHLOROETHANE	BDL	10
16V. 1,1-DICHLOROETHYLENE	BDL	10
17V. 1,2-DICHLOROPROPANE	BDL	10
18V. 1,3-DICHLOROPROPYLENE	BDL	10
19V. ETHYL BENZENE	BDL	10
20V. METHYL BROMIDE	BDL	10
21V. METHYLENE CHLORIDE	BDL	10
22V. 1,1,2,2-TETRACHLOROETHANE	BDL	10
24V. TETRACHLOROETHYLENE	BDL	10
25V. TOLUENE	BDL	10
26V. 1,2-TRANS-DICHLOROETHYLENE	BDL	10
27V. 1,1,1-TRICHLOROETHANE	BDL	10
28V. 1,1,2-TRICHLOROETHANE	BDL	10
29V. TRICHLOROETHYLENE	BDL	10
30V. TRICHLOROFUOROMETHANE	BDL	10
31V. VINYL CHLORIDE	BDL	10

CLW

000006051

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29375
 COMPUCHEM SAMPLE NUMBER: 3496

	<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SC</u> <u>NUM</u>
1A.	2-CHLOROPHENOL	BDL	25	
2A.	2,4-DICHLOROPHENOL	BDL	25	
3A.	2,4-DIMETHYLPHENOL	BDL	25	
4A.	4,6-DINITRO-O-CRESOL	BDL	250	
5A.	2,4-DINITROPHENOL	BDL	250	
6A.	2-NITROPHENOL	BDL	25	
7A.	4-NITROPHENOL	BDL	25	
8A.	P-CHLORO-M-CRESOL	BDL	25	
9A.	PENTACHLOROPHENOL	BDL	25	
10A.	PHENOL	BDL	25	
11A.	2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

000006052

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29375
 COMPUTECH SAMPLE NUMBER: 3496

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006053

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29376
 COMPUCHEM SAMPLE NUMBER: 3497

	<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SI</u> <u>NUM</u>
1V.	ACROLEIN	BDL	100	
2V.	ACRYLONITRILE	BDL	100	
3V.	BENZENE	BDL	10	
4V.	BIS (CHLOROMETHYL) ETHER	BDL	10	
5V.	BROMOFORM	BDL	10	
6V.	CARBON TETRACHLORIDE	BDL	10	
7V.	CHLOROBENZENE	BDL	10	
8V.	CHLORODIBROMOMETHANE	BDL	10	
9V.	CHLOROETHANE	BDL	10	
10V.	2-CHLOROETHYLVINYL ETHER	BDL	10	
11V.	CHLOROFORM	BDL	10	
12V.	DICHLOROBROMOMETHANE	BDL	10	
13V.	DICHLORODIFLUOROMETHANE	BDL	10	
14V.	1,1-DICHLOROETHANE	BDL	10	
15V.	1,2-DICHLOROETHANE	BDL	10	
16V.	1,1-DICHLOROETHYLENE	BDL	10	
17V.	1,2-DICLOROPROPANE	BDL	10	
18V.	1,3-DICLOROPROPYLENE	BDL	10	
19V.	ETHYL BENZENE	BDL	10	
20V.	METHYL BROMIDE	BDL	10	
21V.	METHYL CHLORIDE	BDL	10	
22V.	METHYLENE CHLORIDE	BDL	10	
23V.	1,1,2,2-TETRACHLOROETHANE	BDL	10	
24V.	TETRACHLOROETHYLENE	BDL	10	
25V.	TOLUENE	BDL	10	
26V.	1,2-TRANS-DICHLOROETHYLENE	BDL	10	
27V.	1,1,1-TRICHLOROETHANE	BDL	10	
28V.	1,1,2-TRICHLOROETHANE	BDL	10	
29V.	TRICHLOROETHYLENE	BDL	10	
30V.	TRICHLOROFLUOROMETHANE	BDL	10	
31V.	VINYL CHLORIDE	BDL	10	

CLW

0000006054

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29376
 COMPUTECH SAMPLE NUMBER: 3497

<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1A. 2-CHLOROPHENOL	BDL	25	
2A. 2,4-DICHLOROPHENOL	BDL	25	
3A. 2,4-DIMETHYLPHENOL	BDL	25	
4A. 4,6-DINITRO-O-CRESOL	BDL	250	
5A. 2,4-DINITROPHENOL	BDL	250	
6A. 2-NITROPHENOL	BDL	25	
7A. 4-NITROPHENOL	BDL	25	
8A. P-CHLORO-M-CRESOL	BDL	25	
9A. PENTACHLOROPHENOL	BDL	25	
10A. PHENOL	BDL	25	
11A. 2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

000006055

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29376
 COMPUCHEM SAMPLE NUMBER: 3497

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006056

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29377
 COMPUTECH SAMPLE NUMBER: 3498

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAI</u> <u>NUMBER</u>
1V. ACRYLONITRILE	BDL	100	
2V. BENZENE	BDL	100	
4V. BIS (CHLOROMETHYL) ETHER	BDL	10	
5V. BROMOFORM	BDL	10	
6V. CARBON TETRACHLORIDE	BDL	10	
7V. CHLOROBENZENE	BDL	10	
8V. CHLORODIBROMOMETHANE	BDL	10	
9V. CHLOROETHANE	BDL	10	
10V. 2-CHLOROETHYLVINYL ETHER	BDL	10	
11V. CHLOROFORM	BDL	10	
12V. DICHLOROBROMOMETHANE	BDL	10	
13V. DICHLORODIFLUOROMETHANE	BDL	10	
14V. 1,1-DICHLOROETHANE	BDL	10	
15V. 1,2-DICHLOROETHANE	BDL	10	
16V. 1,1-DICHLOROETHYLENE	BDL	10	
17V. 1,2-DICHLOROPROPANE	BDL	10	
18V. 1,3-DICHLOROPROPYLENE	BDL	10	
19V. ETHYLBENZENE	BDL	10	
20V. METHYL BROMIDE	BDL	10	
21V. METHYL CHLORIDE	BDL	10	
22V. METHYLENE CHLORIDE	BDL	10	
23V. 1,1,2,2-TETRACHLOROETHANE	BDL	10	
24V. TETRACHLOROETHYLENE	BDL	10	
25V. TOLUENE	BDL	10	
26V. 1,2-TRANS-DICHLOROETHYLENE	BDL	10	
27V. 1,1,1-TRICHLOROETHANE	BDL	10	
28V. 1,1,2-TRICHLOROETHANE	BDL	10	
29V. TRICHLOROETHYLENE	BDL	10	
30V. TRICHLOROFUOROMETHANE	BDL	10	
31V. VINYL CHLORIDE	BDL	10	

CLW

000006057

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29377
 COMPUCHEM SAMPLE NUMBER: 3498

<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1A. 2-CHLOROPHENOL	BDL	25	
2A. 2,4-DICHLOROPHENOL	BDL	25	
3A. 2,4-DIMETHYLPHENOL	BDL	25	
4A. 4,6-DINITRO-O-CRESOL	BDL	25	
5A. 2,4-DINITROPHENOL	BDL	250	
6A. 2-NITROPHENOL	BDL	250	
7A. 4-NITROPHENOL	BDL	25	
8A. P-CHLORO-M-CRESOL	BDL	25	
9A. PENTACHLOROPHENOL	BDL	25	
10A. PHENOL	BDL	25	
11A. 2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

000006058

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29377
 COMPUTECH SAMPLE NUMBER: 3498

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>
1P. ALDRIN	BDL	0.1
2P. ALPHA-BHC	BDL	0.1
3P. BETA-BHC	BDL	0.1
4P. GAMMA-BHC	BDL	0.1
5P. DELTA-BHC	BDL	0.1
6P. CHLORDANE	BDL	0.1
7P. 4,4'-DDT	BDL	0.1
8P. 4,4'-DDE	BDL	0.1
9P. 4,4'-DDD	BDL	0.1
10P. DIELDRIN	BDL	0.1
11P. ALPHA-ENDOSULFAN	BDL	0.1
12P. BETA-ENDOSULFAN	BDL	0.1
13P. ENDOSULFAN SULFATE	BDL	0.1
14P. ENDRIN	BDL	0.1
15P. ENDRIN ALDEHYDE	BDL	0.1
16P. HEPTACHLOR	BDL	0.1
17P. HEPTACHLOR EPOXIDE	BDL	0.1
18P. PCB-1242	BDL	0.1
19P. PCB-1254	BDL	0.1
20P. PCB-1221	BDL	0.1
21P. PCB-1232	BDL	0.1
22P. PCB-1248	BDL	0.1
23P. PCB-1260	BDL	0.1
24P. PCB-1016	BDL	0.1
25P. TOXAPHENE	BDL	0.1

CLW

000006059

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
 COMPUCHEM SAMPLE NUMBER: 3499

<u>VOLATILE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1V. ACROLEIN	BDL	100	
2V. ACRYLONITRILE	BDL	100	
3V. BENZENE	BDL	10	
4V. BIS (CHLOROMETHYL) ETHER	BDL	10	
5V. BROMOFORM	BDL	10	
6V. CARBON TETRACHLORIDE	BDL	10	
7V. CHLOROBENZENE	BDL	10	
8V. CHLORODIBROMOMETHANE	BDL	10	
9V. CHLOROETHANE	BDL	10	
10V. 2-CHLOROETHYLVINYL ETHER	BDL	10	
11V. CHLOROFORM	50	10	319
12V. DICHLOROBROMOMETHANE	14	10	406
13V. DICHLORODIFLUOROMETHANE	BDL	10	
14V. 1,1-DICHLOROETHANE	BDL	10	
15V. 1,2-DICHLOROETHANE	BDL	10	
16V. 1,1-DICHLOROETHYLENE	BDL	10	
17V. 1,2-DICHLOROPROPANE	BDL	10	
18V. 1,3-DICHLOROPROPYLENE	BDL	10	
19V. ETHYLBENZENE	BDL	10	
20V. METHYL BROMIDE	BDL	10	
21V. METHYL CHLORIDE	BDL	10	
22V. METHYLENE CHLORIDE	BDL	10	
23V. 1,1,2,2-TETRACHLOROETHANE	BDL	10	
24V. TETRACHLOROETHYLENE	BDL	10	
25V. TOLUENE	BDL	10	
26V. 1,2-TRANS-DICHLOROETHYLENE	BDL	10	
27V. 1,1,1-TRICHLOROETHANE	BDL	10	
28V. 1,1,2-TRICHLOROETHANE	BDL	10	
29V. TRICHLOROETHYLENE	BDL	10	
30V. TRICHLOROFLUOROMETHANE	BDL	10	
31V. VINYL CHLORIDE	BDL	10	

CLW

0000006060

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
 COMPUCHEM SAMPLE NUMBER: 3499

<u>ACID EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1A. 2-CHLOROPHENOL	BDL	25	
2A. 2,4-DICHLOROPHENOL	BDL	25	
3A. 2,4-DIMETHYLPHENOL	BDL	25	
4A. 4,6-DINITRO-O-CRESOL	BDL	250	
5A. 2,4-DINITROPHENOL	BDL	250	
6A. 2-NITROPHENOL	BDL	25	
7A. 4-NITROPHENOL	BDL	25	
8A. P-CHLORO-M-CRESOL	BDL	25	
9A. PENTACHLOROPHENOL	BDL	25	
10A. PHENOL	BDL	25	
11A. 2,4,6-TRICHLOROPHENOL	BDL	25	

CLW

0000006061

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
 COMPUTECH SAMPLE NUMBER: 3499

<u>BASE-NEUTRAL EXTRACTABLE ORGANICS</u>	<u>CONCENTRATION (UG/L)</u>	<u>DETECTION LIMIT (UG/L)</u>	<u>SCAN NUMBER</u>
1B. ACENAPHTHENE	BDL	10	
2B. ACENAPHTHYLENE	BDL	10	
3B. ANTHRACENE	BDL	10	
4B. BENZIDINE	BDL	10	
5B. BENZO (A) ANTHRACENE	BDL	10	
6B. BENZO (A) PYRENE	BDL	10	
7B. 3,4-BENZOFUORANTHENE	BDL	10	
8B. BENZO (GHI) PERYLENE	BDL	25	
9B. BENZO (K) FLUORANTHENE	BDL	10	
10B. BIS (2-CHLOROETHOXY) METHANE	BDL	10	
11B. BIS (2-CHLOROETHYL) ETHER	BDL	10	
12B. BIS (2-CHLOROISOPROPYL) ETHER	BDL	10	
13B. BIS (2-ETHYLHEXYL) PHTHALATE	BDL	10	
14B. 4-BROMOPHENYL PHENYL ETHER	BDL	10	
15B. BUTYL BENZYL PHTHALATE	BDL	10	
16B. 2-CHLORONAPHTHALENE	BDL	10	
17B. 4-CHLOROPHENYL PHENYL ETHER	BDL	10	
18B. CHRYSENE	BDL	10	
19B. DIBENZO (A,H) ANTHRACENE	BDL	25	
20B. 1,2-DICHLOROBENZENE	BDL	10	
21B. 1,3-DICHLOROBENZENE	BDL	10	
22B. 1,4-DICHLOROBENZENE	BDL	10	
23B. 3,3'-DICHLOROBENZIDINE	BDL	10	
24B. DIETHYL PHTHALATE	BDL	10	
25B. DIMETHYL PHTHALATE	BDL	10	
26B. DI-N-BUTYL PHTHALATE	BDL	10	
27B. 2,4-DINITROTOLUENE	BDL	10	
28B. 2,6-DINITROTOLUENE	BDL	10	
29B. DI-N-OCTYL PHTHALATE	BDL	10	
30B. 1,2-DIPHENYLHYDRAZINE	BDL	10	
31B. FLUORANTHENE	BDL	10	
32B. FLUORENE	BDL	10	
33B. HEXACHLOROBENZENE	BDL	10	
34B. HEXACHLOROBUTADIENE	BDL	10	
35B. HEXACHLOROCYCLOPENTADIENE	BDL	10	

Continued...

CLW

0000006062

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
 COMPUCHEM SAMPLE NUMBER: 3499

<u>BASE-NEUTRAL EXTRACTABLE ORGANICS (Continued)</u>	<u>CONCENTRATION (UG/L)</u>	<u>DETECTION LIMIT (UG/L)</u>	<u>SCAN NUMBER</u>
36B. HEXACHLOROETHANE	BDL	10	
37B. INDENO (1,2,3-CD) PYRENE	BDL	25	
38B. ISOPHORONE	BDL	10	
39B. NAPHTHALENE	BDL	10	
40B. NITROBENZENE	BDL	10	
41B. N-NITROSODIMETHYLAMINE	BDL	10	
42B. N-NITROSODI-N-PROPYLAMINE	BDL	10	
43B. N-NITROSODIPHENYLAMINE	BDL	10	
44B. PHENANTHRENE	BDL	10	
45B. PYRENE	BDL	10	
46B. 1,2,4-TRICHLOROBENZENE	BDL	10	

CLW

0000006063

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
 COMPUCHEM SAMPLE NUMBER: 3499

<u>PESTICIDES/PCB'S</u>	<u>CONCENTRATION</u> <u>(UG/L)</u>	<u>DETECTION</u> <u>LIMIT</u> <u>(UG/L)</u>	<u>SCAN</u> <u>NUMBER</u>
1P. ALDRIN	BDL	10	
2P. ALPHA-BHC	BDL	10	
3P. BETA-BHC	BDL	10	
4P. GAMMA-BHC	BDL	10	
5P. DELTA-BHC	BDL	10	
6P. CHLORDANE	BDL	10	
7P. 4,4'-DDT	BDL	10	
8P. 4,4'-DDE	BDL	10	
9P. 4,4'-DDD	BDL	10	
10P. DIELDRIN	BDL	10	
11P. ALPHA-ENDOSULFAN	BDL	10	
12P. BETA-ENDOSULFAN	BDL	10	
13P. ENDOSULFAN SULFATE	BDL	10	
14P. ENDRIN	BDL	10	
15P. ENDRIN ALDEHYDE	BDL	10	
16P. HEPTACHLOR	BDL	10	
17P. HEPTACHLOR EPOXIDE	BDL	10	
18P. PCB-1242	BDL	10	
19P. PCB-1254	BDL	10	
20P. PCB-1221	BDL	10	
21P. PCB-1232	BDL	10	
22P. PCB-1248	BDL	10	
23P. PCB-1260	BDL	10	
24P. PCB-1016	BDL	10	
25P. TOXAPHENE	BDL	10	

CLW

0000006064

BDL = BELOW DETECTION LIMIT

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
COMPUCHEM SAMPLE NUMBER: 3499

<u>INORGANICS</u> <u>PRIORITY POLLUTANTS</u>	<u>CONCENTRATION</u> <u>(MG/L)</u>	<u>DETECTION LIMI</u> <u>(MG/L)</u>
4M. CYANIDE, TOTAL	BDL	0.01

INORGANICS
CONVENTIONALS

(NONE ORDERED)

CLW
000006065

EXHIBIT II - COMPOUND LIST

SAMPLE IDENTIFIER: 29378
COMPUCHEM SAMPLE NUMBER: 3499

<u>INORGANICS</u> <u>PRIORITY POLLUTANTS</u>	<u>CONCENTRATION</u> <u>(MG/L)</u>	<u>DETECTION LIMIT</u> <u>(MG/L)</u>
15. PHENOLS, TOTAL	BDL	0.01

INORGANICS
CONVENTIONALS

(NONE REQUESTED)

CLW

000006066